CAMPBELL HAUSFELD
BUILT TO LAST

Oilless Air Compressors
Compresseurs D'Air Sans Huile
Compresores Sin Aceite

Replacement Parts List
Lista de Repuestos
Liste de Pièces de Rechange

WL650000, WL650100, WL604010, WL650200, WL650300, WL650400

For parts, products & service information visit
POWERXPERT
www.campbellhausfeld.com



© 2000 Campbell Hausfeld

For Replacement Parts, Call 1-800-543-6400

Please provide the following information:
-Model number
-Serial number (if any)
-Part description and number as shown in parts list

Address parts correspondence to:

The Campbell Group
Attn: Parts Dept.
100 Production Drive
Harrison, OH 45030 USA

Ref. No.		Description	Part Number WL650000	WL650100	WL604010	Qty.
1		Top cover	WL008600AV	WL008600AV	WL008600AV	1
2		Lower cover	WL008500AV	WL008500AV	WL008500AV	1
3		Screw	ST074420AV	ST074420AV	ST074420AV	1
4		Screw	ST074415AV	ST074415AV	ST074415AV	7
5		Motor bracket	BA018300AV	BA018300AV	BA018300AV	1
6		Pump/motor assembly	WL390000AJ	WL390000AJ	WL390000AJ	1
7		Compression nut	ST033001AV	ST033001AV	ST033001AV	2
8		Rubber sleeve	ST067300AV	ST067300AV	ST067300AV	2
9		Exhaust tube	WL011200AP	WL011200AP	WL011200AP	1
10		Check valve	CV221506AJ	CV221506AJ	CV221506AJ	1
11	▲	Motor pad	WL007800AV	WL007800AV	WL007800AV	1
12	▲	Isolator	WL008100AV	WL008100AV	WL008100AV	1
13	▲	Grommet	WL008000AV	WL008000AV	WL008000AV	1
14		Tank	AR045000CG	AR045000CG	AR045000CG	1
15		Wheel	WA003900AV	WA003900AV	WA003900AV	2
16		Axle bolt	ST033400AV	ST033400AV	ST033400AV	2
17		Drain cock	D-1401	D-1401	D-1401	1
18		Foot	ST162600AV	ST162600AV	ST162600AV	2
19		Handle	HL004300AV	HL004300AV	HL004300AV	1
20		Pipe nipple	ST070307AV	ST070307AV	ST070307AV	1
21		Pressure switch	CW207589AV	CW207589AV	CW207589AV	1
22		Elbow	ST071202AV	ST071202AV	ST071202AV	1
23		Safety valve	V-215100AV	V-215100AV	V-215100AV	1
24		Adapter	ST071407AV	ST071407AV	ST071407AV	1
25		Gauge	GA016303AV	GA016303AV	GA016303AV	2
26		Regulator	RE206202AV	RE206202AV	RE206202AV	1
27		Nipple	HF007300AV	—	—	2
		Nipple	—	HF007300AV	HF007300AV	1
28		Nut	ST033500AV	ST033500AV	ST033500AV	2
29		Power cord with plug	EC012601AV	EC012601AV	EC012601AV	1
30		Clip	ST166800AV	ST166800AV	ST166800AV	1
31		Flexible tube	ST117804AV	ST117804AV	ST117804AV	1
32		Inlet tube	WL011800AV	WL011800AV	WL011800AV	1
33		Screw	ST073273AV	ST073273AV	ST073273AV	2
34		Nut	ST146000AV	ST146000AV	ST146000AV	2
35		Coupler	MP288300AV	—	—	1
36		Strain relief	CW000703AV	CW000703AV	CW000703AV	1
37		Strain relief screw	ST074418AV	ST074418AV	ST074418AV	1
38		Washer	ST070933AV	ST070933AV	ST070933AV	1
39		Washer	ST077311AV	ST077311AV	ST077311AV	1
40		Screw	ST158400AV	ST158400AV	ST158400AV	1
REPLACEMENT PARTS KITS						
	▲	Isolator kit (Includes #11, 12, 13)	WL211300AJ	WL211300AJ	WL211300AJ	1

CAMPBELL HAUSFELD
BUILT TO LAST

Oilless Air Compressors
Compresseurs D'Air Sans Huile
Compresores Sin Aceite

Replacement Parts List
Lista de Repuestos
Liste de Pièces de Rechange

WL650000, WL650100, WL604010, WL650200, WL650300, WL650400

For parts, products & service information visit
POWER XPERT
www.campbellhausfeld.com



© 2000 Campbell Hausfeld

For parts, product & service information
visit **www.campbellhausfeld.com**

IN224801AV 7/00

For Replacement Parts, Call 1-800-543-6400

Please provide the following information:
-Model number
-Serial number (if any)
-Part description and number as shown in parts list

Address parts correspondence to:

The Campbell Group
Attn: Parts Dept.
100 Production Drive
Harrison, OH 45030 USA

Ref. No.		Description	Part Number WL650200	WL650300	WL650400	Qty.
1		Top cover	WL008600AV	WL008600AV	WL008600AV	1
2		Lower cover	WL008500AV	WL008500AV	WL008500AV	1
3		Screw	ST074420AV	ST074420AV	ST074420AV	1
4		Screw	ST074415AV	ST074415AV	ST074415AV	7
5		Motor bracket	BA018300AV	BA018300AV	BA018300AV	1
6		Pump/motor assembly	WL390000AJ	WL390000AJ	WL390000AJ	1
7		Compression nut	ST033001AV	ST033001AV	ST033001AV	2
8		Rubber sleeve	ST067300AV	ST067300AV	ST067300AV	2
9		Exhaust tube	WL014000AP	WL011200AP	WL011200AP	1
10		Check valve	CV221506AJ	CV221506AJ	CV221506AJ	1
11	▲	Motor pad	WL007800AV	WL007800AV	WL007800AV	1
12	▲	Isolator	WL008100AV	WL008100AV	WL008100AV	1
13	▲	Grommet	WL008000AV	WL008000AV	WL008000AV	1
14		Tank	AR045300CG	AR045400CG	AR045500CG	1
15		Wheel	WA003900AV	WA003900AV	WA003900AV	2
16		Axle bolt	ST033400AV	ST033400AV	ST033400AV	2
17		Drain cock	D-1401	D-1401	D-1401	1
18		Foot	ST162600AV	ST162600AV	ST162600AV	2
19		Handle	HL004300AV	HL004300AV	HL004300AV	1
20		Pipe nipple	ST070375AV	ST070307AV	ST070307AV	1
21		Pressure switch	CW207589AV	CW207589AV	CW207589AV	1
22		Elbow	ST071202AV	ST071202AV	ST071202AV	1
23		Safety valve	V-215100AV	V-215100AV	V-215100AV	1
24		Adapter	ST071407AV	ST071407AV	ST071407AV	1
25		Gauge	GA016303AV	GA016303AV	GA016303AV	2
26		Regulator	RE206202AV	RE206202AV	RE206202AV	1
27		Nipple	HF007300AV	HF007300AV	HF007300AV	1
28		Nut	ST033500AV	ST033500AV	ST033500AV	1
29		Power cord with plug	EC012601AV	EC012601AV	EC012601AV	1
30		Clip	ST166800AV	ST166800AV	ST166800AV	1
31		Flexible tube	ST117804AV	ST117804AV	ST117804AV	1
32		Inlet tube	WL011800AV	WL011800AV	WL011800AV	1
33		Screw	ST073273AV	ST073273AV	ST073273AV	2
34		Nut	ST146000AV	ST146000AV	ST146000AV	2
35		Coupler	—	—	—	1
36		Strain relief	CW000703AV	CW000703AV	CW000703AV	1
37		Strain relief screw	ST074418AV	ST074418AV	ST074418AV	1
38		Washer	ST070933AV	ST070933AV	ST070933AV	1
39		Washer	ST077311AV	ST077311AV	ST077311AV	1
40		Screw	ST158400AV	ST158400AV	ST158400AV	1
REPLACEMENT PARTS KITS						
	▲	Isolator kit (Includes #11, 12, 13)	WL211300AJ	WL211300AJ	WL211300AJ	1